

INSTALLATION INSTRUCTIONS

For all Shallow Water Series™ Aeration Systems
Item # 490354




Table of Contents:

Product Contents	2	Troubleshooting	4
Installation	3	Replacement Parts	4
Maintenance	4	Warranty	4

PRODUCT CONTENTS

The ProAir 2 is the most advanced diffuser on the market today and is specifically designed to maximize circulation and oxygen transfer in ponds and lakes. The ProAir 2's weighted sled design keeps the diffuser submerged and prevents it from sinking into the muck. The exclusive PTFE non-stick membrane sticks provide the synergy of air stones while being virtually maintenance-free. Each diffuser also includes a check valve to prevent back pressure to the compressor.



What's Included:


- A** 1 – Shallow Water Diffuser Sled
- B** 2 – ProAir Diffuser Membrane Stick
- C** 1 – Check Valve, 3/4" FPT
- D** 1 – 5/8" to 3/4", Barb x MPT Insert Reducer Adapter
- E** 1 – 3/8" to 3/4", Barb x MPT Insert Reducer Adapter
- F** 1 – 1" Stainless Hose Clamp

INSTALLATION INSTRUCTIONS

Step 1

Hand tighten Membrane Sticks onto Diffuser Sled.

NOTE: DO NOT over tighten Membrane Sticks. Once snug, continue 1/4 turn. Over tightening may cause **DAMAGE** to the Diffuser Sled and/or Membrane Sticks.



Step 2

Hand tighten Check Valve to the Diffuser Sled.

NOTE: DO NOT over tighten Check Valve. Once snug, continue 1/4 turn. Over tightening may cause **DAMAGE** to the Diffuser Sled and/or Check Valve.



Step 3

Depending on the size of airline, screw corresponding reducer adaptor into the check valve. Slide hose clamp onto the airline and connect airline to the reducer adaptor. Firmly tighten stainless hose clamp onto airline to secure into place.



MAINTENANCE

We recommend inspecting and/or cleaning the membrane diffuser sticks every 24-36 months, or anytime there is a reduction in bubbles from the diffuser. To clean, use Airmax D-Scale Cleaner (#530298) and a soft cloth.

TROUBLESHOOTING

If you have loss of airflow to one or more diffusers:

- Check to ensure airflow valves on compressor manifolds are adjusted correctly.

If large boiling bubbles are present on the water's surface:

- Check membrane sticks for tears.
- Check for loose connections on diffuser manifold.

REPLACEMENT PARTS

REPLACEMENT PARTS	ITEM #
Airmax Shallow Water Diffuser Sled	#490333
Airmax ProAir™ Diffuser Membrane Stick	#510168
1" Stainless Hose Clamp	#490229
Airmax 5/8" to 3/4", Barb x MPT	#490227
Airmax 3/8" to 3/4", Barb x MPT	#490225
Airmax Check Valve, 3/4" FPT	#490340

WARRANTY

All ProAir 2 diffusers carry a 5-year warranty extended exclusively to the original purchaser. This warranty begins from the date of original purchase receipt. Any component which proves to be defective in material or workmanship as determine by Airmax, Inc. will be repaired or replaced at no charge. The end user shall assume all responsibility and expense for removal, packaging and freight to ship to Airmax, Inc. to determine the warranty claim and for all reinstallation expenses.

Improper installation, careless handling, misuse, abuse or failure to follow maintenance or operating instructions as well as any modification or repair by an unauthorized repair facility will void all warranty. Diffuser membranes are considered wear parts and are not covered under warranty.

**THANK YOU FOR CHOOSING:
Airmax, Inc.**

15425 Chets Way Street, Armada, MI 48005
866-424-7629 | www.airmaxeco.com | contactus@airmaxeco.com

#510478 V1.1